ROOMETTES

THE PAINT PROS #01-102-01 AND COMBO R4369

INSTRUCTIONS

- I. REMOVE THE MAIN FLOOR, AS WELL AS THE SERVICE COUNTER TOP AND BASE, FROM THE CARDSTOCK SHEETS WITH A SHARP HOBBY KNIFE. **PO NOT CUT THE DOTTED LINES!** THEY ARE FOR FOLDING.
- 2. CAREFULLY FOLD THE BASE OF THE SERVICE COUNTER TO CREATE A THREE-SIDED BOX WITH 90-DEGREE TABS INSIDE AT THE TOP. **PO NOT OVERBEND THEM!**
- 3. PLACE THE COUNTER TOP UPSIDE DOWN AND GLUE THE TABS OF THE BASE TO IT.
 PLACE A FILLET OF APPITIONAL GLUE IN THE INSIDE CORNERS, SET IT ASIDE TO DRY.
- 4. CREATE WINDOW SHELVES BY ROLLING THE TABS AT THE FRONT OF THE ROOM TO MAKE A BOX. GLUE OTHER SIDE AS SHOWN ON TABS. A SMALL FILE OR SCREWDRIVER CAN BE USED TO APPLY PRESSURE TO THE JOINT FROM INSIDE THE BOX AS IT SETS.
- 5. FOLD THE WALLS OF THE ROOM TO GET A SENSE OF WHERE THE COUNTER WILL SIT IN THE SPACE. USE YOUR KNIFE TO ROUGHEN THE SURFACE OF THE FLOOR BEHIND THE COUNTER FOR IMPROVED ADHESION. GLUE THE COUNTER IN PLACE, BEING GENEROUS WITH ADHESIVE BEHIND IT. YOU DO NOT WANT IT TO COME LOOSE LATER!
- 6. FOLD THE ROOM TOGETHER AND GLUE THE LEFT AND RIGHT WINGS UNDER THE FLOOR. USE A POPSICLE STICK OR SIMILAR TOOL TO CAREFULLY APPLY PRESSURE ON THE FLOOR OVER EACH WING TO SET THE GLUE.
- 7. FLIP THE ROOM OVER AND GLUE THE LEFT AND RIGHT WINGS OVER THE TOP OF THE CEILING.
- 8. CAREFULLY BEND UP THE TAB LABELLED "GLUE TO WALL" AT A RIGHT ANGLE.
- 9. GLUE THE SIGNS SECURELY ON THE WINDOW SHELVES, POSITIONED AS DESIRED.
- 10. ASSEMBLE THE SECOND-FLOOR ROOMS IN A SIMILAR MANNER.
- II. CHECK ALL GLUE JOINTS TO MAKE SURE THEY ARE SOLID BEFORE PROCEEDING.
 TEST FIT THE ROOMS. IF YOU HAVE ASSEMBLED YOUR BUILDING ACCORDING TO THE
 MANUFACTURER'S INSTRUCTIONS THEY SHOULD FIT EASILY. IF YOU FIND THEY FIT
 TOO TIGHT VERTICALLY YOU CAN REMOVE SOME OF THE WALL-MOUNT TAB MATERIAL
 WITH SCISSORS FOR ADDITIONAL CLEARANCE. TO PREVENT LIGHT LEAKAGE, SPREAD
 A BIT OF GLUE INTO THE PERFORATED SEAMS ON THE CORNERS OF THE ROOM FROM
 THE OUTSIDE. THIS WILL ALSO MAKE THE JOINTS STRONGER.
- 12. LISE YOUR KNIFE TO REMOVE THE CEILING PLUGS AND INSTALL PROVIDED LEDS, FASTENING THEM IN PLACE WITH GOOD QUALITY TAPE OR GLUE.
- 13. STARTING WITH THE UPPER FLOORS GLUE THE ROOMS TO THE WALL, BEING CAREFUL NOT TO GET GLUE ON YOUR CLEAR WINDOW MATERIAL.
- 14. GLUE THE SIGN OVER THE POORWAY ON THE FRONT OF THE BUILDING.
- 15. PLUG THE LEP HARNESS INTO YOUR WOODLAND SCENICS' JUST PLUG' OR NCE ILLUMINATOR MODULE. SIT BACK AND ENJOY YOUR EFFORTS!

THIS IS NOT A TOY.

NOT SUITABLE FOR CHILDREN

UNDER 14 YEARS OF AGE.