

THEME KIT

TEPEE VILLAGE KIT SP4133

INSTRUCTIONS

Micro Sticky Spots (Fig. 1 and 2)

- How to Apply Sticky Spots to Sticks:** Press Stick onto Sticky Spot, then roll Stick across Sticky Spot to remove it from the backing paper. Adhesive should wrap around Stick. (Fig. 1)
- How to Apply Sticky Spots to Paper:** Press a Sticky Spot onto the area marked with • and lift off the backing paper. (Fig. 2)
- Tepee/Accessories Legend:**
 - X Shows where to attach Sticks.
 - Press Sticky Spots directly onto this area.

Tepees (Figs. 3, 4 and 5)

- Punch out Tepees and Tepee Doors. Sketch symbols with a pencil and color with acrylic paint. Let dry. See front of label for examples.
 - Fold Tepee flaps outwards along dotted lines. (Fig. 3)
 - Apply Sticky Spots on • marks along inner front edge. Curve Tepee into a tent shape and press front edges together. (Fig. 3)
 - Mark Sticks at 3 5/8 in (9.20 cm) (or use Tepee Pole Guide on Tepee Sheet) and cut with scissors. Cut six Sticks per Tepee. Save extra pieces for later use.
 - Attach a Sticky Spot to one end of a Stick and another 2 in (5.08 cm) higher. Starting at the front door, press Sticks into place where indicated on inside of Tepee. (Fig. 4)
- NOTE:** The X marks serve as placement guides for sticks.
- Tepee Doors:** From leftover Stick material, cut two 1 in (2.54 cm) pieces per Tepee. Attach a Sticky Spot in the center of each Stick. Press Sticks into place where indicated on backside of Tepee Door. Attach Tepee Doors to Tepee. (Fig. 5)

Canoes (Figs. 6 and 7)

- Punch out Canoes.
- Crease along dotted lines (diamond pattern) to help shape Canoe more easily. (Fig. 6)
- Apply Sticky Spots where indicated at ends of Canoes, and then press ends together. (Fig. 6)
- Cut two 5/8 in (1.58 cm) pieces of leftover Stick for centers of the Canoes Attach Sticky Spot to ends of Sticks and press in place. (Fig. 7)

Paddles (Fig. 8)

- Punch out Paddles. Use 1 3/8 in (3.49 cm) pieces of Stick for handles.
- Apply Sticky Spot where indicated on backside of paddle. Press Stick onto Sticky Spot, fold Paddle over and press together.












Drying Rack (Fig. 9, 10 and 11)

- Cut Sticks for drying rack: two 1 1/8 in (2.85 cm) pieces and three 1 1/2 in (3.81 cm) pieces per Animal Hide.
- Attach two Sticky Spots to each 1 1/8 in (2.85 cm) piece of Stick, using X marks on backside of Hide as a placement guide. Press Sticks onto Hide. Then, press on two 1 1/2 in (3.81 cm) pieces to form rack shape.
- Apply a Sticky Spot to both ends of 1 1/2 in (3.81 cm) piece. Press one end onto center of upper Stick and other Sticky Spot will hold drying rack in place on diorama.

NOTE: The 1 1/2 in (3.81 cm) pieces that make up the legs may need to be placed on the Drying Racks so they are longer at the bottom in order for the Drying Racks to stand up properly.

Fire Pits (Fig. 12)

- Punch out Fire Pits and place where desired on diorama.
- Attach with a Sticky Spot.
- Arrange leftover Sticks to model firewood.



Conforms to /
Conforme à /
Cumple con
ASTM D4236

CAUTION: Cutting tool recommended. Use with care.
MISE EN GARDE: Outil de coupe recommandé. Utiliser avec précaution.
PRECAUCIÓN: Herramienta cortante recomendada. Utilizar con cuidado.

WARNING: Sharp Objects. Choking Hazard! Small parts. Not intended for children under 3 years. Adult supervision required. / **AVERTISSEMENT:** Objets pointus. Danger d'étranglement! Petites pièces. Pas recommandé pour les enfants de moins de 3 ans. Supervision d'un adulte requise. / **ADVERTENCIA:** Objetos puntiagudos. Peligro de ahogarse. Partes pequeñas. No diseñado para el uso de niños menores de 3 años. Supervisión de un adulto requerida.