

# THEME KIT

## HOME KIT SP4244

### INSTRUCTIONS

#### Micro Sticky Spots (Fig. 1)

1. **How to Apply Sticky Spots to Paper:** Press a Sticky Spot onto the area marked with • and lift off the backing paper.

#### Prepare Parts

1. All cutouts that are printed on the cardstock are pre-cut. Punch out each component along the pre-cut solid lines.
2. Keep parts for each different cutout together.

**NOTE:** Some cutouts have labels on the back for reference.

#### House Walls (Fig. 2 and 3)

1. Bend all Wall tabs (A1), (A2), (B1), (C1) and (D1) to 90° angles.
2. Fold (A1) and (A2) on scored lines to create the front door inset (Fig. 2).

**NOTE:** The front door should be positioned so that it is set back in an alcove the Walls create around it. The leftmost tab of (A2) goes behind the front door.

3. Attach (A1) to (A2) by applying Sticky Spots to • markings on (A2) left tab. Press edges together firmly. (Fig. 2)
4. Apply Sticky Spots to • markings of (A1) left tab and align with untabbed edge of (B1). Press into place.
5. Apply Sticky Spots to • markings of (B1) left tab and align with untabbed edge of (C1). Press into place.
6. Apply Sticky Spots to • markings of (C1) left tab and align with untabbed edge of (D1). Press into place.
7. Apply Sticky Spots to • markings of (D1) left tab and align with edge of (A2). Press into place. (Fig. 3)

#### House Roof (Fig. 4 and 5)

1. Bend Roof tabs at 90° angles.
2. Apply Sticky Spots to • markings on tabs of (E2). Place House Back Roof (E2) on the backside of the untabbed edge of the House Front Roof (E1), making sure the Roof pieces are flush with one another. Set aside.
3. Create Dormer by folding (E3) on scored line to create a tent. Fold tabs outward at 90° angles.
4. Apply Sticky Spots to • markings on (E3) tabs and slide it under the Roof and into wedge of (E1), following the contour of the open wedge. (Fig. 4)







5. Attach House Roof by applying Sticky Spots to • markings on (A1), (A2), (B1), (C1) and (D1) Roof tabs and press on Roof with (E3) resting over the front door, following the contours of the House. (Fig. 5)

#### Chimney (Fig. 6)

1. Finish your Roof with the Chimney. Fold Chimney on score lines to create a rectangular shape, open end up.
2. Apply Sticky Spots to • markings on tab and press edges together.
3. Attach Chimney by applying one Sticky Spot to bottom of Chimney. With the tallest brick section facing forward, press Chimney onto Roof near peak.

#### Garage (Fig. 7)

1. Bend all Wall tabs (A3), (B3), (C3) and (D3) back at 90° angles.
2. Apply Sticky Spots to • markings on (A3) left tab and align with untabbed right edge of (B3). Press into place.
3. Apply Sticky Spots to • markings on (C3) right tab and align with untabbed left edge of (B3). Press into place.
4. Apply Sticky Spots to • markings on (C3) left tab and align with untabbed right edge of (D3). Press into place.
5. Apply Sticky Spots to • markings on (A3) right tab and align with untabbed left edge of (D3). Press into place.
6. Attach Garage Roof by applying Sticky Spots to • markings on (B3) and (D3) Roof tabs. Fold Roof on scored line and press on Roof, following the contour of the House.
7. If desired, attach Garage to House by applying Sticky Spots.



Conforms to /  
Conforme à /  
Cumple con  
ASTM D4236

**CAUTION:** Cutting tool recommended. Use with care.  
**MISE EN GARDE :** Outil de coupe recommandé. Utiliser avec précaution.  
**PRECAUCIÓN:** Herramienta cortante recomendada Utilizar con cuidado.

**WARNING:** Sharp Objects. Choking Hazard! Small parts. Not intended for children under 3 years. Adult supervision required. / **AVERTISSEMENT :** Objets pointus. Danger d'étranglement! Petites pièces. Pas recommandé pour les enfants de moins de 3 ans. Supervision d'un adulte requise. / **ADVERTENCIA:** Objetos puntiagudos. Peligro de ahogarse. Partes pequeñas. No diseñado para el uso de niños menores de 3 años. Supervisión de un adulto requerida.